

Hex Control Code	Decimal Control Code	Name/Function			
\$05	05	CURSOR ON-OFF—Allows alteration of the cursor based on the value of the next character. Codes are as follow:			
		Hex	Dec	Char	Function
		\$20	32	space	Cursor OFF
		\$21	33	!	Cursor ON
		\$22	34	"	Cursor ON
		\$23	35	#	Cursor ON
		\$24	36	\$	Cursor ON
		\$25	37	%	Cursor ON
		\$26	38	&	Cursor ON
		\$27	39	'	Cursor ON
		\$28	40	(Cursor ON
		\$29	41)	Cursor ON
		\$2A	42	*	Cursor ON
\$06	06	CURSOR RIGHT—Moves the cursor to the right one character position.			
\$07	07	BELL—Sounds a bell (beep) through monitor speaker.			
\$08	08	CURSOR LEFT—Moves the cursor to the left one character position.			
\$09	09	CURSOR UP—Moves the cursor up one line.			
\$0A	10	CURSOR DOWN (linefeed)—Moves the cursor down one line.			
\$0C	12	CLEAR SCREEN—Erases the entire screen, and homes the cursor (positions it at the upper left corner of the screen).			
\$0D	13	RETURN—Returns the cursor to the leftmost character on the line.			
\$0E	14	DISPLAY ALPHA—Switches the screen from Graphic mode to Alphanumeric mode.			