

Key Combination	Control Function or Character
CTRL A	Repeats the previous command line.
CTRL D	Redisplays the command line.
CTRL W	Temporarily halts output to the screen. Press any key to resume output.
CTRL CLEAR	Enable/Disable Keyboard mouse.
CLEAR	Change screens.
SHIFT CLEAR	Change screens in reverse order.
ENTER	