

SS.DScrn

(Function code \$8C). Causes VDGINT to display a screen that was allocated by SS.AScrn

Entry Conditions:

- A = *path number*
- B = \$8C
- Y = *screen number*
 - 0 = text screen (32 x 16)
 - 1-3 = high resolution screen number

Error Output:

- CC = carry set on error
- B = *error code* (if any)

Additional Information:

- SS.DScrn shows the requested screen if the requested screen is the current interactive device.
- Screen 0 (text screen) should be selected before using SS.FSCrn to free all high resolution screen memory.
- The support module for this call is VDGINT.